

SHO-ME®

MODEL NO. 11.1010SF 4 Output LED Flasher GENERAL INFORMATION

FLASH PATTERNS:


Mode 1 (Gray wire) & Mode 2 (Brown wire): Double Alternating , Quad Alternating , Mega Alternating , Quint Simultaneous , Simultaneous , Quad Simultaneous , Random.

Mode 3 (Green wire): Scan , Sweep , Alternate 1-2 & 3-4 , Quad Alternate 1-2 & 3-4 , Quad Alternate 1-3 & 2-4 Alternate 1-3 & 2-4 , Random.

The Gray Mode 1 wire operates outputs 1&2 , The Brown Mode 2 wire operates outputs 3&4.
The Green Mode 3 wire operates all outputs .

INSTALLATION INSTRUCTIONS:

1. Find location where the LED flasher (Shown in diagram below) will be mounted. Mark holes to be drilled. Mount the LED flasher with screws included.
2. Wire the LED flasher as shown in the diagram below.



PRODUCTS COMPANY • 804 East Hwy. 248 • Cassville, MO 65625
U.S. and Canada Toll Free Numbers • Phone: 800-641-4098 FAX: 800-526-1240
E-mail: sales@able2products.com WEB: www.able2products.com