



MODEL NO. 11.2731  
LED Signal Stick  
Complete with Controller

**GENERAL INFORMATION**

The LED Signal Stick alerts traffic in the direction they need to follow. The Signal Stick (Model No. 11.1031) comes complete with controller (Model No. 11.1006). The controller has an ON/OFF switch, Rotary switch, and Speed Control Dial. **NOTE:** Shielded wire must be grounded at the Controller. The LED Stick has twelve flash patterns from which to choose:


- |                                  |                           |
|----------------------------------|---------------------------|
| 1. Random flash - (Patterns 2-7) | 7. Left 3 Right 3         |
| 2. Quad Flash 2-2                | 8. Center Out             |
| 3. Quad Flash 3-3                | 9. Right * w/Double Flash |
| 4. Double Flash 2-2              | 10. Right                 |
| 5. Double Flash 3-3              | 11. Left * w/Double Flash |
| 6. Center 2 Outer 2              | 12. Left                  |

**INSTALLATION INSTRUCTIONS**

Use the L-brackets (included) to mount the LED Signal Stick. To install mounting bolts to the signal stick, remove the 4 screws from the end cap and install the mounting bolts into the desired t-slot as shown in drawing, then re-install the end cap.

**WIRING INSTRUCTIONS:**

Black wire to Ground, Red wire to Positive +12V and Yellow wire to Spst Toggle switch +12v DC (Optional). Yellow wire activates the signal stick in a Random Flash Pattern when +12v is applied. When operating signal stick with controller, All Signal Stick functions will override the Random Flash.



**PRODUCTS COMPANY** 804 East Hwy 248 Cassville, MO 65625  
U.S. and Canada Toll Free Numbers Phone: 800-641-4098 FAX: 800-526-1240  
E-mail: sales@able2products.com WEB: www.able2products.com