


12 Selectable Flash Patterns - Controller Model 11.1006

Random

Quad Flash 2-2



Quad Flash 3-3




Center Out




Double Flash 3-3




Double Flash 2-2



Left Arrow



Left Arrow - Double Flash




Center 2 / Outer 2



Alternating 3-3



Right Arrow



Right Arrow - Double Flash

