



MODEL NO. 11.2741
LED Signal Stick
with 33.1000 Controller


GENERAL INFORMATION

The LED Signal Stick alerts traffic in the direction they need to follow. The Signal Stick (Model No. 11.1041) comes complete with controller (Model No. 33.1000). The controller has an ON/OFF switch, Rotary switch and Speed Control Dial. **NOTE:** Sheilded wire must be grounded at the Controller. The LED Signal Stick has twelve flash patterns from which to choose:

- | | |
|----------------------------------|---------------------------|
| 1. Random Flash - (Patterns 2-7) | 7. Left 4 Right 4 |
| 2. Quad Flash 2-2 | 8. Center Out |
| 3. Quad Flash 4-4 | 9. Right * w/Double Flash |
| 4. Double Flash 2-2 | 10. Right |
| 5. Double Flash 4-4 | 11. Left * w/Double Flash |
| 6. Center 2 Outer 2 | 12. Left |

INSTALLATION INSTRUCTIONS

Use the L- brackets (included) to mount the LED Signal Stick. To install mounting bolts to the signal stick, remove 4 screws from the end cap and install the mounting bolts into the desired t-slot as shown in drawing, then re-install the end cap.



PRODUCTS COMPANY • 804 East Hwy. 248 • Cassville, MO 65625
U.S. and Canada Toll Free Numbers • Phone: 800-641-4098 FAX: 800-526-1240
E-mail: sales@able2products.com WEB: www.able2products.com