



# LIGHT STORM<sup>®</sup>

## LED Signal Stick

### MODEL NO. 12.6206

### GENERAL INFORMATION

The LED Signal Stick alerts traffic in the direction they need to follow. The Signal Stick comes complete with controller (Model No. 11.1006). The controller has an ON/OFF Switch, Rotary Switch and Speed Control Dial. **NOTE:** Shielded wire must be grounded at the Controller. The LED Signal Stick has twelve flash patterns from which to choose:


- |                                  |                     |                           |
|----------------------------------|---------------------|---------------------------|
| 1. Random Flash - (Patterns 2-7) | 5. Double Flash 3-3 | 9. Right * w/Double Flash |
| 2. Quad Flash 2-2                | 6. Center 2 Outer 1 | 10. Right                 |
| 3. Quad Flash 3-3                | 7. Left 3 Right 3   | 11. Left * w/Double Flash |
| 4. Double Flash 2-2              | 8. Center Out       | 12. Left                  |

### INSTALLATION INSTRUCTIONS

Use the L - brackets (included) to mount the 12.6206 light. To install mounting bolts to the signal stick, remove the 4 screws from the end cap and install the mounting bolts into the desired t-slot as shown in drawing. Re-install the end cap.

### WIRING INSTRUCTIONS

Black wire to Ground, Red wire to Positive +12V. Yellow wire activates the signal stick in a Random Flash Pattern when +12v is applied. When operating signal stick with controller, All Signal Stick functions will override the Random Flash.



**PRODUCTS COMPANY** 804 East Hwy 248 Cassville, MO 65625  
 U.S. and Canada Toll Free Numbers Phone: 800-641-4098 FAX: 800-526-1240  
 E-mail: sales@able2products.com WEB: www.able2products.com