



Controller Model 11.1000 for Signal Stick Model 12.6210


Double Flash 3-3




Left Arrow




Right Arrow




Double Flash 5-5




Left Arrow - Double Flash




Right Arrow - Double Flash




Center 2 / Outer 4




Center Out



Quad Flash 3-3



Quad Flash 5-5



Left 5 Right 5



Random Flash